

TEST REPORT IEC 62109-2

Safety of Power Converter for use in Photovoltaic Power Systems Part 2: Particular requirements for inverters

Report Number. 210901903SHA-002

Name of Testing Laboratory Intertek Testing Services Shanghai

200233, China

Applicant's name...... Afore New Energy Technology (Shanghai) Co., Ltd

Address Build No.7, 333 Wanfang Road, Minhang District,

Shanghai. China. 201112

Test specification:

Standard.....: IEC/EN 62109-2:2011

Test procedure CE-LVD

Non-standard test method N/A

Test Report Form No.....: IEC62109 2B

Test Report Form(s) Originator: LCIE - Laboratoire Central des Industries Electriques

Master TRF...... Dated 2016-11

Copyright © 2016 IEC System of Conformity Assessment Schemes for Electrotechnical Equipment and Components (IECEE System). All rights reserved.

This publication may be reproduced in whole or in part for non-commercial purposes as long as the IECEE is acknowledged as copyright owner and source of the material. IECEE takes no responsibility for and will not assume liability for damages resulting from the reader's interpretation of the reproduced material due to its placement and context.



Page 2 of 26

Report No. 210901903SHA-002

item description:	PV Grid interactive inverter
Trade Mark:	Afore
Manufacturer:	Same as applicant
Model/Type reference:	BNT003KTL, BNT004KTL, BNT005KTL, BNT006KTL, BNT008KTL, BNT010KTL, BNT012KTL, BNT015KTL, BNT017KTL, BNT020KTL, BNT025KTL
Ratings:	See Specifications table in report of 210901903SHA -001



Res	oonsible Testing Laboratory (as applical	ole), testing procedure and testi	ng location(s):
\boxtimes	Testing Laboratory:	Intertek Testing Services Shangh	nai
Test	ing location/ address:	Building No.86, 1198 Qinzhou Ro 200233, China	oad (North), Shanghai
	Associated CB Testing Laboratory:		
Test	ing location/ address:		
Test	ed by (name, function, signature):	Chuanhui Xie (Engineer)	Chuan hui Xie
Арр	roved by (name, function, signature) :	Sleif Sui (Mandated Reviewer)	Sleifsni
		Ι	
	Testing procedure: CTF Stage 1:		
Test	ing location/ address::		
Test	ed by (name, function, signature):		
App	roved by (name, function, signature):		
		T	
Ш	Testing procedure: CTF Stage 2:		
Test	ing location/ address::		
Test	ed by (name + signature):		
Witn	essed by (name, function, signature).:		
App	roved by (name, function, signature):		
	Tooting proceedings CTF Store 2		
H	Testing procedure: CTF Stage 3:		
	Testing procedure: CTF Stage 4:		
Test	ing location/ address:		
Test	ed by (name, function, signature):		
Witn	essed by (name, function, signature).:		
App	roved by (name, function, signature):		
Sup	ervised by (name, function, signature) :		




List of Attac	List of Attachments (including a total number of pages in each attachment):		
C	i taatin ma All taata oo	04.00 0.0044	
_	f testing : All tests were carried out according to IEC 6		
Tests perfor	med (name of test and test clause):	Testing location:	
⊠4.4.4 □4.7.4	Testing in single fault condition Stand-alone Inverter AC output voltage and	Building No.86, 1198 Qinzhou Road (North), Shanghai 200233, China	
	frequency		
☐4.7.5	Stand-alone inverter output voltage waveform		
⊠4.8.2	Array insulation resistance detection for inverters for ungrounded and functionally grounded arrays		
⊠4.8.3	Array residual current detection		
Summary of	compliance with National Differences (List of count	ries addressed):	
N/A	•	,	
	uct fulfils the requirements of IEC/EN 62109-2:2011		



Copy of marking plate:

The artwork below may be only a draft. The use of certification marks on a product must be authorized by the respective NCBs that own these marks.



Series No.

T622500032149820

Remark:

1.Printed symbols shall be at least 2.75 mm high. Printed text characters shall be at least 1.5 mm high, whether upper case or lower case, and shall contrast in colour with the background 2.The tenth to thirteenth of the serial number (2149): 21=year 49=week.



Warning marking WARNING Hot surfaces To reduce the risk of burns. Do not touch. Risk of electric shock Both AC and DC voltage sources are terminated inside this equipment. Each circuit must be individually disconnected before servicing and when the photovoltaic array is exposed to light, it supplies a DC voltage to this equipment. Risk of electric shock from energy stored in capacitor. Do not remove cover until 5 minutes after disconnecting all sources of supply. Risk of electric shock, do not remove cover. No user serviceable parts inside. Refer servicing to qualified service personnel. Check user manual before service Refer to the operation instruction. NO warranty for disassembled inverter Warranty doesn't provide for the inverter disassembled by POWER FED FROM MORE WARNING: THAN ONE SOURCE For continued protection against risk of fire, replace only with same type and ratings of fuse. [] Electronic Materials Please scan the QR code below with your mobile phone to obtain relevant electronic information. (MONITORING APP) (e USER MANUAL)



Report No. 210901903SHA-002



Test item particulars:	
Equipment mobility	☐ movable☐ hand-held☐ stationary☐ for building-in
Connection to the mains	☐ pluggable equipment ☐ direct plug-in ☐ for building-in
Enviromental category:	
Over voltage category Mains:	
Over voltage category PV	
Mains supply tolerance (%):	-90 / +110 %
Tested for power systems:	TN
IT testing, phase-phase voltage (V)::	
Class of equipment:	
Mass of equipment (kg):	Max. 19 KG
Pollution degree::	PD3 (PD2 internal)
IP protection class:	IP65
Possible test case verdicts:	
- test case does not apply to the test object:	N/A
- test object does meet the requirement:	P (Pass)
- test object does not meet the requirement:	F (Fail)
Testing:	
Date of receipt of test item:	2021-08-24
Date (s) of performance of tests:	2021-08-25 to 2021-12-05



General remarks:	
"(See Enclosure #)" refers to additional information app "(See appended table)" refers to a table appended to the	•
Throughout this report a \square comma / \boxtimes point is us	ed as the decimal separator.
Standard IEC/EN 62109-2:2011 is to be used in conjur	oction with IEC/EN 62109-1:2010.
The test results presented in this report relate only to the complies with standards" IEC/EN 62109-1:2010 and IEC	
Determination of the test conclusion is based on IEC Gu uncertainty.	ide 115 in consideration of measurement
This report is for the exclusive use of Intertek's Client and is provided p	ons of the agreement. Intertek assumes no liability to any party, and then only in its entirety. Any use of the Intertek name or one of or service must first be approved in writing by Intertek. The ple tested. This report by itself does not imply that the material,
Manufacturer's Declaration per sub-clause 4.2.5 of II	ECEE 02:
The application for obtaining a CB Test Certificate	Yes
includes more than one factory location and a declaration from the Manufacturer stating that the sample(s) submitted for evaluation is (are) representative of the products from each factory has been provided	Not applicable ■
When differences exist; they shall be identified in the	e General product information section.
Name and address of factory (ies):	Same as applicant




General product information:

The testing unit is a Class I grid-interactive PV inverter for outdoor installation (IP65).

The unit is providing EMC filtering at the output toward mains.

The unit does not provide galvanic separation from input to output (transformerless).

The output is switched off redundant by the high power switching bridge and two relays. This assures that the opening of the output circuit will also operate in case of one is error.



The product was tested on Software version:

CPU1: DSP V06 CPU2: CPLD V06

CPU3(Communication): HMI V06

Model difference:

All models have same circuit, PWB layout and software. And difference between models are output rating, PV input string number and fan number.

Model BNT003KTL, BNT004KTL, BNT005KTL, BNT006KTL, BNT010KTL, BNT012KTL, BNT013KTL have 2 PV input strings.

Model BNT015KTL have 3 PV input strings

Model BNT017KTL, BNT020KTL, BNT025KTL have 4 PV input strings.

Model BNT003KTL, BNT004KTL, BNT005KTL, BNT006KTL have no external fan.

Model BNT008KTL, BNT010KTL, BNT012KTL have 1 external fan.

Model BNT013KTL, BNT015KTL, BNT017KTL, BNT020KTL, BNT025KTL have 2 external fans.

The output power is derated by software.

Except as noted, the model BNT25KTL is as the representative test model in this report.



4.4.4 Single fault conditions to be applied P 4.4.4.15 Fault-tolerance of protection for grid-interactive inverters inverters Fault-tolerance of residual current monitoring according to 4.8.3.5: the residual current monitoring system operates properly a) The inverter ceases to operate - Indicates a fault in accordance with §13.9 - Disconnect from the mains - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting Doth PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - the residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 - The inverter continues to operate regardless of loss of residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 - In or re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not r		IEC 62109-2		
4.4.15 Single fault conditions to be applied P	Clause	Requirement + Test	Result - Remark	Verdict
4.4.4.15 Single fault conditions to be applied P A.4.4.15 Fault-tolerance of protection for grid-interactive inverters P A.4.4.15.1 Fault-tolerance of residual current monitoring system operates properly a) The inverter ceases to operate P Disconnect from the mains P Disconnect from the mains P Disconnect from the mains P Disconnect from the mains P P Disconnect from the mains		1	1	l
A.4.4.15 Fault-tolerance of protection for grid-interactive inverters P	= =	GENERAL TESTING REQUIREMENTS		Р
Inverters Pault-tolerance of residual current monitoring according to 4.8.3.5: the residual current monitoring system operates properly a). The inverter ceases to operate P Indicates a fault in accordance with §13.9 P Disconnect from the mains P P On the connect after any sequence of removing and reconnecting PV power P On the connect after any sequence of removing and reconnecting AC power P On the reconnect after any sequence of removing and reconnecting both PV and AC power P P On the reconnect after any sequence of removing and reconnecting both PV and AC power P P P P P P P P P	4.4.4	Single fault conditions to be applied		Р
according to 4.8.3.5: the residual current monitoring system operates properly a) - The inverter ceases to operate - Indicates a fault in accordance with §13.9 - Disconnect from the mains - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power Disconnect from the mains P	4.4.4.15	•		Р
Policates a fault in accordance with §13.9 Policates a fault with a single fault applied to the disconnect all grounded current-carrying conductors from the mains when the disconnecting means is intended to be in the open postate. Policates a fault applied to the disconnecting with requirements of 7.3.7 of Part 1: report here Part 1 Policates a fault in the open position	4.4.4.15.1	according to 4.8.3.5: the residual current monitoring		Р
- Disconnect from the mains - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - the residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 - not re-connect after any sequence of removing and reconnecting reproduced by a factor of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - lindicates a fault in accordance with §13.9 - Relay - Pault-tolerance of automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.5 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		a) The inverter ceases to operate		Р
- not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - his inverter continues to operate the residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 - Fault-tolerance of automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		 Indicates a fault in accordance with §13.9 		Р
and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - hot re-connect after any sequence of removing and reconnecting single fault condition - Indicates a fault in accordance with §13.9 - Indicates a fault in accordance with §13.9 - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 - Indicates a fault in		- Disconnect from the mains		Р
- not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power b). The inverter continues to operate - the residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 c). The inverter continues to operate regardless of loss of residual current monitoring functionality - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 - Indicates a fault in accordance with §13.9 The means provided for automatic disconnecting means - disconnect all grounded current-carrying conductors from the mains - disconnect all urgrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.7 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position				Р
- not re-connect after any sequence of removing and reconnecting both PV and AC power b). The inverter continues to operate N/A		- not re-connect after any sequence of removing		Р
b) The inverter continues to operate the residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 c) The inverter continues to operate regardless of loss of residual current monitoring functionality - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting by P and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all ungrounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		- not re-connect after any sequence of removing		Р
- the residual current monitoring system operates properly under single fault condition - Indicates a fault in accordance with §13.9 c) The inverter continues to operate regardless of loss of residual current monitoring functionality - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnecting means The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. Pro non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position				N/A
- Indicates a fault in accordance with §13.9 c) - The inverter continues to operate regardless of loss of residual current monitoring functionality - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnecting means - Indicates a fault in accordance with §13.9 4.4.4.15.2.1 The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		- the residual current monitoring system operates		N/A
c) The inverter continues to operate regardless of loss of residual current monitoring functionality - not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnecting means - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position				N/A
- not re-connect after any sequence of removing and reconnecting PV power - not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnecting means The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		c) The inverter continues to operate regardless of		N/A
- not re-connect after any sequence of removing and reconnecting AC power - not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnecting means 4.4.4.15.2.1 The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position N/A Relay P Relay P A.4.4.15.2.9 See appended table 4.4.4.15.2 Fault-tolerance of automatic disconnecting P P A.4.4.15.2.2 Fault-tolerance of automatic disconnecting.		- not re-connect after any sequence of removing		N/A
- not re-connect after any sequence of removing and reconnecting both PV and AC power - Indicates a fault in accordance with §13.9 4.4.4.15.2.1 The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position N/A Relay P Relay P A.4.4.15.2.2 See appended table 4.4.4.15.2 Fault-tolerance of automatic disconnecting P A.4.4.15.2 Fault-tolerance of automatic checking of the isolation provided by a disconnect means after single fault. P If the check fail: - any still-functional disconnection means shall be left in the open position		- not re-connect after any sequence of removing		N/A
- Indicates a fault in accordance with §13.9 4.4.4.15.2 Fault-tolerance of automatic disconnecting means 4.4.4.15.2.1 The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		 not re-connect after any sequence of removing 		N/A
4.4.4.15.2.1 Fault-tolerance of automatic disconnecting means Relay P				N/A
4.4.4.15.2.1 The means provided for automatic disconnection of a grid-interactive inverter from the mains shall: - disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position	4.4.4.15.2		Relay	
- disconnect all grounded current-carrying conductors from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position			Thomas,	
from the mains - disconnect all ungrounded current-carrying conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		a grid-interactive inverter from the mains shall:		
conductors from the mains - be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position See appended table 4.4.4.15.2 Fault-tolerance of automatic disconnecting. P				Р
- be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state. 4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position P 4.4.4.15.2 Fault-tolerance of automatic disconnecting. P 4.4.4.15.2 Fault-tolerance of automatic disconnecting.		•		Р
4.4.4.15.2.2 Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict. 4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position		be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is	4.4.4.15.2 Fault-tolerance of	Р
4.4.4.15.2.3 For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault. If the check fail: - any still-functional disconnection means shall be left in the open position See appended test table 4.4.4.15.2 Fault-tolerance of automatic disconnecting.	4.4.4.15.2.2	Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1		Р
If the check fail: - any still-functional disconnection means shall be left in the open position	4.4.4.15.2.3	For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after	4.4.4.15.2 Fault-tolerance of	Р
		If the check fail: - any still-functional disconnection means shall be	adomatic disconnecting.	Р
- at least basic or simple separation shall be			1	D



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
		T	1
	maintained between the PV input and the mains		
	- the inverter shall not start operation		<u> P</u>
	- the inverter shall indicate a fault in accordance with 13.9		P
4.4.4.16	A stand-alone inverter with a transfer switch to transfer AC loads from the mains or other AC bypass source to the inverter output:	Grid-Interactive inverter	N/A
	- shall continue to operate normally		N/A
	shall not present a risk of fire as the result of an out- of-phase transfer		N/A
	shall not present a risk of shock as the result of an out-of-phase transfer		N/A
	And having control preventing switching: components for malfunctioning:		N/A
4.4.4.17	Cooling system failure – Blanketing test No hazards according to the criteria of sub-clause 4.4.3 of Part 1 shall result from blanketing the inverter This test is not required for inverters restricted to use only in closed electrical operating areas.	See appended test table Cooling system failure – Blanketing test.	P
	Test stop condition: time duration value or stabilized temperature	stabilized temperature	Р
4.7	ELECTRICAL RATINGS TESTS		N/A
4.7.4	Stand-alone Inverter AC output voltage and frequency	у	N/A
4.7.4.1	General	Grid-Interactive inverter	N/A
4.7.4.2	Steady state output voltage at nominal DC input The steady-state AC output voltage shall not be less than 90 % or more than 110 % of the rated nominal voltage with the inverter supplied with its nominal value of DC input voltage.		N/A
4.7.4.3	Steady state output voltage across the DC input range The steady-state AC output voltage shall not be less than 85 % or more than 110 % of the rated nominal voltage with the inverter supplied with any value within the rated range of DC input voltage.		N/A
4.7.4.4	Load step response of the output voltage at nominal DC input The AC output voltage shall not be less than 85 % or more than 110 % of the rated nominal voltage for more than 1,5 s after application or removal of a resistive load.		N/A
4.7.4.5	Steady state output frequency The steady-state AC output frequency shall not vary from the nominal value by more than +4 % or -6 %.		N/A
4.7.5	Stand-alone inverter output voltage waveform		N/A
4.7.5.1	General		N/A
4.7.5.2	The AC output voltage waveform of a sinusoidal output stand-alone inverter shall have a total harmonic distortion (THD) not exceeding of 10 % and no individual harmonic at a level exceeding 6 %.		N/A
4.7.5.3	Non-sinusoidal output waveform requirements		N/A
4.7.5.3.1	General		N/A

Page 11 of 26



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
4.7.5.3.2	The total harmonic distortion (THD) of the voltage waveform shall not exceed 40 %.		N/A
4.7.5.3.3	The slope of the rising and falling edges of the positive and negative half-cycles of the voltage waveform shall not exceed 10 V/µs measured between the points at which the waveform has a voltage of 10 % and 90 % of the peak voltage for that half-cycle.		N/A
4.7.5.3.4	The absolute value of the peak voltage of the positive and negative half-cycles of the waveform shall not exceed 1,414 times 110 % of the RMS value of the rated nominal AC output voltage.		N/A
4.7.5.4	Information requirements for non-sinusoidal waveforms The instructions provided with a stand-alone inverter not complying with 4.7.5.2 shall include the information in 5.3.2.6.		N/A
4.7.5.5	Output voltage waveform requirements for inverters For an inverter that is intended only for use with a kn following requirements may be used as an alternative requirements in 4.7.5.2 to 4.7.5.3.	own dedicated load, the	N/A
	The combination of the inverter and dedicated load shall be evaluated to ensure that the output waveform does not cause any hazards in the load equipment and inverter, or cause the load equipment to fail to comply with the applicable product safety standards.		N/A
	The inverter shall be marked with symbols 9 and 15 of Table C.1 of Part 1.		N/A
	The installation instructions provided with the inverter shall include the information in 5.3.2.13.		N/A
4.8	ADDITIONAL TESTS FOR GRID-INTERACTIVE INVER	RTERS	Р
4.8.1	General requirements regarding inverter isolation and array grounding	No-Isolated	N/A
	- Type of Array grounding supported:		N/A
	- Inverter isolation:		N/A
4.8.2	Array insulation resistance detection for inverters for ungrounded and functionally grounded arrays	(See attached table)	Р
4.8.2.1	Array insulation resistance detection for inverters for ungrounded arrays		Р
	Inverter shall have means to measure DC insulation resistance from PV input (array) to ground before starting operation,		P
	Or Inverter shall be provided with instruction in accordance with 5.3.2.11.		N/A
	Measured DC insulation resistance:		Р
	Inverter measurement circuit shall be capable of detecting insulation resistance below the limit value R= Vmax/30mA under normal conditions		Р
	Inverter measurement circuit shall be capable of detecting insulation resistance below the limit value R= Vmax/30mA with ground fault in the PV array		Р
	Isolated inverters shall indicate a fault if the insulation resistance is less than the limit value		N/A



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
	Isolated inverter fault indication maintained until	1	N/A
	insulation resistance has recovered to a value higher		IN/A
	than the limit value		
	Non-isolated inverters, or inverters with isolation not complimits in the minimum inverter isolation requirements in Ta		Р
	- shall indicate a fault in accordance with 13.9		Р
	- shall not connect to the mains		P
4.8.2.2	Array insulation resistance detection for inverters	No functionally grounded	N/A
	for functionally grounded arrays	arrays	
	a-1) The value of the total resistance, including the		N/A
	intentional resistance for array functional grounding, the		
	expected insulation resistance of the array to ground,		
	and the resistance of any other networks connected to		
	ground (for example measurement networks) must not		
	be lower than R = (VMAX PV/30 mA) ohms.		
	a-2) The installation instructions shall include the		N/A
	information required in 5.3.2.12.		
	b-1) As an alternative to a), or if a resistor value lower		N/A
	than in a) is used, the inverter shall incorporate means		
	to detect, during operation, if the total current through		
	the resistor and any networks (for example		
	measurement networks) in parallel with it, exceeds the		
	residual current values and times in Table 31		
	b-2) Inverter shall either disconnect the resistor or limit		N/A
	the current by other means:		
	b-3) If the inverter is a non-isolated inverter, or has		N/A
	isolation not complying with the leakage current limits in		
	the minimum inverter isolation requirements in Table 30,		
	it shall also disconnect from the mains.		
	c) The inverter shall have means to measure the DC		N/A
	insulation resistance from the PV input to ground before		
100	starting operation, in accordance with 4.8.2.1.		
4.8.3	Array residual current detection	I	P
4.8.3.1	General		P
4.8.3.2	30 mA touch current type test for isolated inverters		N/A
4.8.3.3	Fire hazard residual current type test for isolated inverters		N/A
4.8.3.4	Protection by application of RCD's	Without such function.	N/A
	- The requirement for additional protection in 4.8.3.1		
	can be met by provision of an RCD with a residual		
	current setting of 30 mA, located between the		
	inverter and the mains.		
	- The selection of the RCD type to ensure		N/A
	compatibility with the inverter must be made		
	according to rules for RCD selection in Part 1.		
	- The RCD provided integral to the inverter, or		N/A
	- The RDC provided by the installer if details of the		N/A
	rating, type, and location for the RCD are given in		
	the installation instructions per 5.3.2.9.		<u> </u>
4.8.3.5	Protection by residual current monitoring		Р
4.8.3.5.1	General		Р
	Where required by Table 30, the inverter shall provide		Р

Page 13 of 26



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
	residual current monitoring that functions whenever the		
	inverter is connected to the mains with the automatic		
	disconnection means closed.		
	The residual current monitoring means shall measure		Р
	the total (both a.c. and d.c. components) RMS current.		
	As indicated in Table 30 for different inverter types,		Р
	array types, and inverter isolation levels, detection may		
	be required for excessive continuous residual current,		
	excessive sudden changes in residual current, or both, according to the following limits:		
	a) Continuous residual current: The inverter shall disconn	ect within 0.3 s and indicate a	P
	fault in accordance with 13.9 if the continuous residual cu		'
	- maximum 300 mA for inverters with continuous		Р
	output power rating ≤30kVA;		
	- maximum 10 mA per kVA of rated continuous		N/A
	output power for inverters with continuous output		
	power rating > 30 kVA.		
	The inverter may attempt to re-connect if the array		Р
	insulation resistance meets the limit in 4.8.2.		
	b) Sudden changes in residual current: The inverter		Р
	shall disconnect from the mains within the time specified		
	in Table 31		
	The inverter indicates a fault in accordance with 13.9, if a sudden increase in the RMS residual current is		Р
	detected exceeding the value in the table.		
	The inverter may attempt to re-connect if the array		Р
	insulation resistance meets the limit in 4.8.2.		'
4.8.3.5.2	Test for detection of excessive continuous residual	See appended test table	Р
	current: test repeated 5 times and time to	4.8.3.5.2 Test for detection of	
	disconnect shall not exceed 0,3 s.	excessive continuous residual	
		current	
4.8.3.5.3	Test for detection of sudden changes in residual		Р
	current repeated 5 times and each of the 5 results		
	shall not exceed the time limit indicated in for each		
4000	row (30mA, 60mA and150mA) of Table 31.		N 1/A
4.8.3.6	Systems located in closed electrical operating areas		N/A
	The protection against shock hazard is not required		N/A
	if the installation information provided with the inverter indicates the restriction for use in a closed		
	electrical operating area, and		
	Installation information indicates what forms of shock		N/A
	hazard protection are and are not provided integral to		1 11/7
	the inverter, in accordance with 5.3.2.7.		
	The inverter shall be marked as in 5.2.2.6.		N/A
5	MARKING AND DOCUMENTATION		P
5.1	Marking		Р
5.1.4	Equipment ratings		Р
	PV input ratings:		Р
	- Vmax PV (absolute maximum) (d.c. V)		Р
	- Isc PV (absolute maximum) (d.c. A)		Р
	a.c. output ratings:		Р
	- Voltage (nominal or range) (a.c. V)		Р



Page 15 of 26

	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
			1
	- Current (maximum continuous) (a.c. A)		Р
	- Frequency (nominal or range) (Hz)		Р
	- Power (maximum continuous) (W or VA)		Р
	- Power factor range		Р
	a.c input ratings:	No a.c. input	N/A
	- Voltage (nominal or range) (a.c. V)	·	N/A
	- Current (maximum continuous) (a.c. A)		N/A
	- Frequency (nominal or range) (Hz)		N/A
	d.c. output ratings:	No d.c output	N/A
	- Voltage (nominal or range) (d.c. V)	·	N/A
	- Current (maximum continuous) (d.c. A)		N/A
	Protective class (I or II or III)		Р
	Ingress protection (IP) rating per part 1		Р
	An inverter that is adjustable for more than one		N/A
	nominal output voltage shall be marked to indicate the		
	particular voltage for which it is set when shipped from		
	the factory.		
5.2	Warning markings		Р
5.2.2	Content for warning markings		Р
5.2.2.6	Inverters for closed electrical operating areas		N/A
	Where required by 4.8.3.6, an inverter not provided		N/A
	with full protection against shock hazard on the PV		
	array shall be marked with a warning that the inverter		
	is only for use in a closed electrical operating area, and		
	referring to the installation instructions.		
5.3	Documentation		P
5.3.2	Information related to installation		Р
5.3.2.1	Ratings. Subclause 5.3.2 of Part 1 requires the docu		Р
	information for each input and output. For inverters this information shall be as in Table 33 below. Only those ratings that are applicable based on the type of		
	inverter are required.	able based on the type of	
	PV input quantities:		Р
	- Vmax PV (absolute maximum) (d.c. V)		P
	- PV input operating voltage range (d.c. V)		P
	- Maximum operating PV input current (d.c. A)		P
	- Isc PV (absolute maximum) (d.c. A)		P
	- Max. inverter backfeed current to the array (a.c. or	0A	P
	d.c. A)	0/1	
	a.c. output quantities:		Р
	- Voltage (nominal or range) (a.c. V)		P
	- Current (maximum continuous) (a.c. A)		P
	- Current (inrush) (a.c. A, peak and duration)		P
	- Frequency (nominal or range) (Hz)		P
	- Power (maximum continuous) (W or VA)		P
	- Power factor range		P
	- Maximum output fault current (a.c. A, peak and		P
	duration or RMS)		
	- Maximum output overcurrent protection (a.c. A)		Р
	a.c. input quantities:		N/A
	- Voltage (nominal or range) (a.c. V)		N/A
	- Current (maximum continuous) (a.c. A)	+	N/A



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
		T	1 31/4
	- Current (inrush) (a.c. A, peak and duration)		N/A
	- Frequency (nominal or range) (Hz)		N/A
	d.c input (other than PV) quantities:		N/A
	- Voltage (nominal or range) (d.c. V)		N/A
	- Nominal battery voltage (d.c. V)		N/A
	- Current (maximum continuous) (d.c. A)		N/A
	d.c. output quantities:		N/A
	- Voltage (nominal or range) (d.c. V)		N/A
	- Nominal battery voltage (d.c. V)		N/A
	- Current (maximum continuous) (d.c. A)		N/A
	Protective class (I or II or III)		Р
	Ingress protection (IP) rating per part 1		Р
5.3.2.2	Grid-interactive inverter setpoints		N/A
	For a grid-interactive unit with field adjustable trip	Non-adjustable to operator,	N/A
	points, trip times, or reconnect times, the presence of	Pre-set by manufacturer	
	such controls, the means for adjustment, the factory	before shipment	
	default values, and the limits of the ranges of		
	adjustability shall be provided in the documentation for		
	the PCE or in other format such as on a website.		
	Provided solution:		NI/A
	The setting of field adjustable setpoints shall be		N/A
5.3.2.3	accessible from the PCE		NI/A
3.3.Z.3	Transformers and isolation	No transformer between PV	N/A N/A
	Whether an internal isolation transformer is provided, and if so, what level of insulation (functional, basic,	and AC main	IN/A
	reinforced, or double) is provided by that transformer.	and AC main	
	The instructions shall also indicate what the resulting		
	installation requirements are regarding such things as		
	earthing or not earthing the array, providing external		
	residual current detection devices, etc.		
	An inverter shall be provided with information to the insta	aller regarding.	N/A
	- providing of internal isolation transformer		N/A
	- the level of insulation (functional, basic, reinforced,		N/A
	or double)		1 177 1
	The instructions shall also indicate what the resulting installation requirements are		N/A
	regarding:	·	
	- earthing or not earthing the array		N/A
	- providing external residual current detection		N/A
	devices		
	- requiring an external isolation transformer,		N/A
5.3.2.4	Transformers required but not provided		N/A
	An inverter that requires an external isolation transformed		
	shall be provided with instructions that specify, and for the external isolation		N/A
	transformer with which it is intended to be used:		
	- the configuration type		N/A
	- electrical ratings		N/A
	- environmental ratings		N/A
5.3.2.5	PV modules for non-isolated inverters		Р
	Non-isolated inverters shall be provided with		Р
	installation instructions that require PV modules that		
	have an IEC 61730 Class A rating		1



	IEC 62109-2	
Clause	Requirement + Test Result - Remark	Verdict
		•
	If the maximum AC mains operating voltage is higher	N/A
	than the PV array maximum system voltage, then the	
	instructions shall require PV modules that have a	
	maximum system voltage rating based upon the AC	
	mains voltage.	
5.3.2.6	Non-sinusoidal output waveform information	N/A
	The instruction manual for a stand-alone inverter not complying with 4.7.5.2 shall include a warning that:	N/A
	- the waveform is not sinusoidal,	N/A
	- some loads may experience increased heating,	N/A
	- the user should consult the manufacturers of the	N/A
	intended load equipment before operating that load with the inverter	
	The inverter manufacturer shall provide information regarding:	-
	- what types of loads may experience increased	N/A
	heating	
	recommendations for maximum operating times with such loads	N/A
	The inverter manufacturer shall specify for the waveforms as determined by the testing in 4.7.5.3.2 through 4.7.5.3.4.:	-
	- THD	N/A
	- slope	N/A
	- peak voltage	N/A
5.3.2.7	Systems located in closed electrical operating	N/A
0.0.2.7	areas	1 1,71
	Where required by 4.8.3.6, an inverter not provided with full protection against shock	N/A
	hazard on the PV array shall be provided with installation instructions:	,,
	- requiring that the inverter and the array must be	N/A
	installed in closed electrical operating areas	
	- indicating which forms of shock hazard protection	N/A
	are and are not provided integral to the inverter (for	
	example the RCD, isolation transformer complying	
	with the 30 mA touch current limit, or residual	
	current monitoring for sudden changes)	
5.3.2.8	Stand-alone inverter output circuit bonding	N/A
	Where required by 7.3.10, the documentation for an inverter shall include the following:	N/A
	- if output circuit bonding is required but is not	N/A
	provided integral to the inverter, the required	
	means shall be described in the installation	
	instructions, including which conductor is to be	
	bonded and the required current carrying capability	
	or cross-section of the bonding means;	
<u> </u>	- if the output circuit is intended to be floating, the	N/A
	documentation for the inverter shall indicate that	
	the output is floating.	
5.3.2.9	Protection by application of RCD's	N/A
. <u></u>	Where the requirement for additional protection in	N/A
	4.8.3.1 is met by requiring an RCD that is not provided	
	integral to the inverter, as allowed by 4.8.3.4, the	
	installation instructions shall state the need for the RCD,	

Page 18 of 26

	IEC 62109-2	
Clause	Requirement + Test Result - Remark	Verdict
	and shall specify its rating, type, and required circuit location	N/A
5.3.2.10	Remote indication of faults	Р
	The installation instructions shall include an explanation of how to properly make connections to (where applicable), and use, the electrical or electronic fault indication required by 13.9.	P
5.3.2.11	External array insulation resistance measurement and response	N/A
	The installation instructions for an inverter for use with ungrounded arrays that does not incorporate all the aspects of the insulation resistance measurement and response requirements in 4.8.2.1, must include:	N/A
	- for isolated inverters: an explanation of what aspects of array insulation resistance measurement and response are not provided, and	N/A
	an instruction to consult local regulations to determine if any additional functions are required or not;	N/A
	for non-isolated inverters: an explanation of what external equipment must be provided in the system, and	N/A
	- what the setpoints and response implemented by that equipment must be, and:	N/A
	- how that equipment is to be interfaced with the rest of the system.	N/A
5.3.2.12	Array functional grounding information	N/A
	Where approach a) of 4.8.2.2 is used, the installation instructions for the inverter shall include all of the following:	N/A
	a) the value of the total resistance between the PV circuit and ground integral to the inverter	N/A
	b) the minimum array insulation resistance to ground that system designer or installer must meet when selecting the PV panel and system design, based on the minimum value that the design of the PV functional grounding in the inverter was based on;	N/A
	c) the minimum value of the total resistance R = VMAX PV/30 mA that the system must meet, with an explanation of how to calculate the total;	N/A
	d) a warning that there is a risk of shock hazard if the total minimum resistance requirement is not met.	N/A
5.3.2.13	Stand-alone inverters for dedicated loads	N/A
	Where the approach of 4.7.5.5 is used, the installation instructions for the inverter shall include a warning that the inverter is only to be used with the dedicated load for which it was evaluated, and	N/A
	shall specify the dedicated load.	N/A
5.3.2.14	Identification of firmware version(s)	P
J.V.MIT	An inverter utilizing firmware for any protective functions shall provide means to identify the firmware version.	P



	IEC 62109-2					
Clause	Requirement + Test	Result - Remark	Verdict			
	This can be a marking, but the information can also be	By communication or display	Р			
	provided by a display panel, communications port or	panel				
-	any other type of user interface	TROY HAZARRO	_			
7.3	PROTECTION AGAINST ELECTRIC SHOCK AND ENE	RGY HAZARDS	P P			
	Protection against electric shock					
7.3.10	Additional requirements for stand-alone inverters One circuit conductor bonded to earth to create a	Grid-interactive inverter	N/A N/A			
	grounded conductor and an earthed system.	Grid-interactive inverter	IN/A			
	The means used to bond the grounded conductor to		N/A			
	protective earth provided within the inverter or		IN//A			
	as part of the installation		N/A			
	If not provided integral to the inverter, the required		N/A			
	means shall be described in the installation instructions		13/73			
	as per 5.3.2.8.					
	The means used to bond the grounded conductor to		N/A			
	protective earth shall comply with the requirements for					
	protective bonding in Part 1,					
	If the bond can only ever carry fault currents in stand-		N/A			
	alone mode, the maximum current for the bond is					
	determined by the inverter maximum output fault					
	current.					
	Output circuit bonding arrangements shall ensure that		N/A			
	in any mode of operation, the system only has the					
	grounded circuit conductor bonded to earth in one					
	place at a time.					
	Switching arrangements may be used, in which case		N/A			
	the switching device used is to be subjected to the					
	bond impedance test along with the rest of the bonding					
	path		NI/A			
	Inverters intended to have a circuit conductor bonded		N/A			
	to earth shall not impose any normal current on the bond except for leakage current.					
	Outputs that are intentionally floating with no circuit		N/A			
	conductor bonded to ground, must not have any		IN/A			
	voltages with respect to ground that are a shock					
	hazard in accordance with Clause 7 of Parts 1 and 2.					
	The documentation for the inverter shall indicate that		N/A			
	the output is floating as per 5.3.2.8.					
7.3.11	Functionally grounded arrays		N/A			
	All PV conductors in a functionally grounded array		N/A			
	shall be treated as being live parts with respect to					
	protection against electric shock.					
9	PROTECTION AGAINST FIRE HAZARDS		Р			
9.3	Short-circuit and overcurrent protection		Р			
9.3.4	Inverter backfeed current onto the array		Р			
	The backfeed current testing and documentation require	ments in Part 1 apply,	Р			
	including but not limited to the following.					
	Inverter backfeed current onto the PV array maximum		Р			
	value					
	This inverter backfeed current value shall be provided		Р			
	in the installation instructions regardless of the value of					
<u> </u>	the current, in accordance with Table 33.					



Page 20 of 26

Report No. 210901903SHA-002

	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict

13	PHYSICAL REQUIREMENTS	Р		
13.9	Fault indication			
	Where this Part 2 requires the inverter to indicate a fault, both of the following shall be provided:			
	a) a visible or audible indication, integral to the inverter, and detectable from outside the inverter, and	Р		
	b) an electrical or electronic indication that can be remotely accessed and used.	Р		
	The installation instructions shall include information regarding how to properly make connections (where applicable) and use the electrical or electronic means in b) above, in accordance with 5.3.2.10.	Р		



4.4.4	TABLE: Single	fault condition	on to be ap	plied			Р
	Ambient temperature (°C):						_
Power source for EUT: Manufacturer, model/type, output rating:					_		
4.4.4.15.1 Fault-tolerance of residual current monitoring							
Component No.	Fault	Supply voltage	Test time	Fuse #	Fuse current(A)	Observation	1
GFCI check	R 869 Short Circuit	520Vdc/23 0Vac	3 min	-	-	Unit can't operate, error LeakCurrFault	massage:
						no danger, no hazard, r	o fire
GFCI check	R 554 Open Circuit	520Vdc/23 0Vac	3 min	-	-	Unit can't operate, error massage: LeakCurrFault	
						no danger, no hazard, r	no fire
Check that the	Check that the residual current monitoring operates properly Yes						
Supplementary	information:						

4.4.4	TABLE: Single f	ault condition	on to be a	TABLE: Single fault condition to be applied				
	Ambient temperature (°C):						_	
	Power source for model/type, out			:			_	
4.4.4.15.2	Fault-tolerance	of automatic	disconne	ecting mea	ans			
Component No.	Fault	Supply voltage (V)	Test time	Fuse #	Fuse current (A)	Observation		
Relay (ALFG2)	short circuit before starting up	PV:450V	10min	1	1	Unit can't operate, error massage: Relay 1 Fault No danger, no hazard, r	:	
Relay (ALFG3)	short circuit before starting up	PV:450V	10min	1	1	Unit can't operate, error massage: Relay 1 Fault No danger, no hazard, no fires		
	relays fulfil the b		on or simp	ole separa	tion based	Yes		
Each active pha	ase can be switch	ned. (Land N)			Yes		
Supplementary	information:							



4.4.4.17	Cooling system fainlure – Blanketing test		Р
	Model:	BNT006KTL	_
	Test voltage (Vdc):	620	_
	Test current (Idc):	10	_
	Test voltage (Vac):	230	_
	Test current (lac):	8.7	_
maximum	temperature T of part/at:	T (°C)	T _{max} (°C)
1.	Ambient temp.	42	-
2.	Front enclosure	70	90
3.	Rear enclosure	74	90
4.	Left enclosure	67	90
5.	Right enclosure	74	90
6.	Bottom enclosure	70	90
7.	Top enclosure	75	90
8.	Mounting Surface	71	90
Suppleme	ntary information:		·

4.4.4.17	Cooling system fainlure – Blanketing test		Р
	Model:	BNT012KTL	_
	Test voltage (Vdc):	620	_
	Test current (Idc):	20	_
	Test voltage (Vac):	230	_
	Test current (lac):	17.5	_
maximum	temperature T of part/at:	T (°C)	T _{max} (°C)
1.	Ambient temp.	33	-
2.	Front enclosure	68	90
3.	Rear enclosure	72	90
4.	Left enclosure	66	90
5.	Right enclosure	73	90
6.	Bottom enclosure	72	90
7.	Top enclosure	61	90
8.	Mounting Surface	72	90



4.4.4.17	Cooling system fainlure – Blanketing test		Р
	Model:	BNT025KTL	_
	Test voltage (Vdc):	700	_
	Test current (Idc):	35.7	_
	Test voltage (Vac):	230	_
	Test current (lac):	36.2	_
maximum temperature T of part/at:		T (°C)	T _{max} (°C)
1.	Ambient temp.	30	-
2.	Front enclosure	77	90
3.	Rear enclosure	76	90
4.	Left enclosure	76	90
5.	Right enclosure	73	90
6.	Bottom enclosure	73	90
7.	Top enclosure	73	90
8.	Mounting Surface	71	90
Suppleme	ntary information:		

TABLE: Steady state Inverter AC output voltage and frequency					
Nominal DC input (\	/)				
Nominal output AC	voltage (V) :				
Frequency (Hz)	Condition/status	Comments			
	Without load				
	Resistive load application				
	Resistive load removal				
	Nominal DC input (\nimega) Nominal output AC	Nominal DC input (V) Nominal output AC voltage (V): Frequency (Hz) Condition/status Without load Resistive load application	Nominal DC input (V) Nominal output AC voltage (V): Frequency (Hz) Without load Resistive load application		



4.8.2		ABLE: Array insulation resistance detection for inverters for ungrounded P and functionally grounded arrays					
4.8.2.1	Array	Array insulation resistance detection for inverters for ungrounded arrays					
DC Voltage b minimum ope voltage (V)		DC Voltage for inverter begin operation (V)	Resistance between ground and PV input terminal (kΩ)	Required Insulation resistance R = (V _{MAX PV} / 30mA) (kΩ)	Re	esult	
			DC+				
					Fault informati	on: Isolation	
140		200	50	36.67	And repeat five	e times	
	DC-						
140		200	50	36.67	Fault informati Fault	on: Isolation	
					And repeat five	e times	

Note:

For isolated inverters, shall indicate a fault in accordance with 13.9 (operation is allowed); the fault indication shall be maintained until the array insulation resistance has recovered to a value higher than the limit above For non-isolated inverters, or inverters with isolation not complying with the leakage current limits in the minimum inverter isolation requirements in Table 30, shall indicate a fault in accordance with 13.9, and shall not connect to the mains; the inverter may continue to make the measurement, may stop indicating a fault and may connect to the mains if the array insulation resistance has recovered to a value higher than the limit above.

It is not required to test all PV input terminals if analysis of the design indicates that one or more terminals can be expected to have the same result, for example where multiple PV string inputs are in parallel.

Supplementary information:


All models have same setting, the Max power model tested for typical model.

4.8.3.2	TABLE: 30mA touch	current type test for isolated invert	ters	N/A
C	ondition	Current (mA)	Limit (30mA)	
De	C+ to PE	-	30mA	
D	C- to PE	-	30mA	

Supplementary information:

The touch current measurement circuit of IEC 60990, Figure 4 is connected from each terminal of the array to ground, one at a time.

4.8.3.3	TABLE: Fire hazard	residual current type test for isolate	ed inverters	N/A
	Condition	Current (mA)	Limit (300mA or 10mA pe	r kVA)
ı	DC+ to PE	-	300mA	
	DC- to PE	-	300mA	
Supplementa	ary information:			





4.8.3.5	TABLE: Pro	tection by residual current monitoring	Р
Test co	nditions:	Output power (kVA): 20 Input voltage (V _{DC}): 650 Frequency (Hz):50Hz Output AC Voltage (V _{AC}):230V	
4.8.3.5.2	Test for det	ection of excessive continuous residual current	Р

	Fault Current (mA)	Disconnection time (ms)		
Measured Fault Current	Limit 300mA for output power ≤ 30 kVA 10mA per kVA for output power > 30 kVA	Measured Disconnection time	Limit	
	+	· PV to N:		
195mA	300mA	128 ms	300	
195mA	300mA	128 ms	300	
195mA	300mA	127 ms	300	
195mA	300mA	125 ms	300	
195mA	300mA	131 ms	300	
		- PV to N:		
195mA	300mA	130 ms	300	
195mA	300mA	123 ms	300	
195mA	300mA	126 ms	300	
195mA	300mA	137 ms	300	
195mA	300mA	129 ms	300	

Note:

- maximum 300mA for inverters with continuous output power rating ≤30 kVA;
- maximum 10mA per kVA of rated continuous output power for inverters with continuous output power rating > 30 kVA.

This test shall be repeated 5 times, and for all 5 tests the time to disconnect shall not exceed 0,3s. The test is repeated for each PV input terminal. It is not required to test all PV input terminals if analysis of the design indicates that one or more terminals can be expected to have the same result, for example where multiple PV string inputs are in parallel.

Supplementary information:

All models have same setting, the Max power model tested for typical model.

TABLE: Test for detection of sudden changes in residual current

Р



4.8.3.5.3

	+PV to N	
Limit (mA)	U _N	Limit (ms)
	Disconnection time (ms)	
30	158	300
30	156	300
30	153	300
30	177	300
30	146	300
60	83	150
60	109	150
60	94	150
60	94	150
60	96	150
150	23	40
150	25	40
150	27	40
150	21	40
150	29	40
130	-PV to N	40
	U _N	
Limit (mA)	Disconnection time (ms)	Limit (ms)
30	145	300
30	175	300
30	180	300
30	140	300
30	148	300
	140	
60	107	150
60	103	150
60	104	150
60	80	150
60	88	150
150	26	40
	27	40
150	<u>~'</u>	
150 150	30	40
150	30	40 40
	30 21 23	40 40 40

End of Test Report

Supplementary information: All models have the same setting, the Max power model tested for typical model.